

# Pairing Your Remote Control System For Systems Made In 2019

Most RFHero Remotes Control Systems manufactured *in 2019* will have a learn/pairing button located on the **OUTSIDE** of the **Receiver**. If your **Receiver** does not have an external learn/pairing button, use the manual for pairing **Systems built before 2019**.



External Learn Button



1. Locate the External Learn Button on the **Receiver**.
2. Make sure the **Transmitter** (Handheld) has batteries and appears to be functioning. Cycle power to the **Receiver**. You have 60 seconds to complete the Learn Mode procedure once step 2 is complete.
3. After the Communications LED flashes three (3) times, press and hold the Learn button on the **Receiver**.
4. Press and hold the Off button on the **Transmitter**.
5. Release the Off button on the **Transmitter** and the Learn button on the **Receiver**.
6. The Communications LED on the **Receiver** should now flash green/red (may appear orange) when a button on the **Transmitter** is pressed.
7. The **Transmitter** and **Receiver** are now paired together.



This System Qualifies for  
Manufacturer Support  
[www.rfhero.net/support](http://www.rfhero.net/support)  
Email: [service@rfhero.com](mailto:service@rfhero.com)  
Phone: (724) 610-5256